

# SWISS ARMY VEHICLES

## Service Information for Steyr Puch Pinzgauer

### Turnsignal Switch Conversion

#### Wiring for a Austrian Turnsignal Switch to a Swiss Army Pinzgauer

Unplug the old turnsignal switch wire by wire and replace it with the same wire of the new switch. This will leave three wires still hooked up on the old switch

black / purple wire = unhook connection it will no longer be used

black / red wire = leave plugged in but cut it off about 5" towards the old switch  
hook up to black/green wire which is on a 3way connection

black / yellow wire = leave plugged in but cut it off about 5" towards the old switch  
hook up to black/white wire which is on a 3way connection

You also need a Red Brake Light conversion to make this work !  
like SAV3503 or SAV3525 LED Taillights  
Conversion Instruction is included for refrence

#### Turnsignal Wire Chart

##### Wires Colors

<u>on Vehicle</u>	<u>old Switch</u>	<u>new Switch</u>
brown	brown/white	brown/white
white	black/white/green	black/white/green
ground connector	brown	brown
black/green (3 way connection)	black/green	black/green
black/white (3 way connection)	black/white	black/white